



FABRICATION OF NANOPOROUS PLATINUM FILMS WITH DEALLOYING METHOD FOR HYDROGEN SENSOR APPLICATION

Melike Sener¹, Ali Altuntepe², Recep Zan^{2,3} and Necmettin Kilinc^{1*}

mlksener44@gmail.com

Inonu University, Department of Physics, Malatya, Türkiye

9th International Electronic Conference on Sensors and Applications (1–15 November 2022)



1. INTRODUCTION

Why do we need hydrogen?











Hydrogen gas is

- colorless,
- odorless,
- tasteless and
- cannot be detected by the human senses







Where are metal and metal alloy nanomaterials used?







Dealloying, which is one of the nanoporous material production methods.









2. MATERIALS AND METHODS





ECSA-9

Fig 1: A Schematic Description Nanoporous Pt With Dealloying Method

9th International Electronic Conference on Sensors and Applications (1–15 November 2022)









Fig. 2. A schematic description for nanoporous Pt sensor device and gas measurements system.

9th International Electronic Conference on Sensors and Applications (1–15 November 2022)



3. RESULTS





ECSA-9

Figure 3: SEM images of Pt-Cu alloys dealloyed in 1 M nitric acid solution at different times (a: no dealloying, b: 15 min, c: 30 min, d: 1 hour)

9th International Electronic Conference on Sensors and Applications (1–15 November 2022)





Figure 4. (a) SEM image of Pt-Cu alloys before dealloying; (b) SEM image of Pt-Cu alloys after dealloying in 1 M HNO₃ at 5 hours; (c) shows the peaks of the elements in the Pt-Cu alloy before dealloying; (d) shows the element peaks of nanoporous Pt dealloyed in 1 M HNO3 solution for 5 hours.

9th International Electronic Conference on Sensors and Applications (1–15 November 2022)





ECSA-9

Figure 5. The resistance versus time graph (a) and sensitivity as a function of concetration chart (b) of nanoporous Pt film exposed to wide hydrogen concentration (10ppm – 5%) at the temperature of 150 °C. (c) The sensitivity versus temperature curve of nanoporous Pt exposed to 1% hydrogen.

9th International Electronic Conference on Sensors and Applications (1–15 November 2022)



Under dry air condition, the surface of Pt is with adsorbed

While the hydrogen exposed to Pt surfaces, hydrogen atoms start to displace oxygen on the surface. (2)

If Hydrogen concentration is high enough, the surface is fully covered Hydrogen atoms.(3)

The resistance of Pt decreases, when exposed hydrogen could be related to decreasing the number of the surface charge carrier scattering.

This process is reversible.

oxygen. (1)





THANK YOU FOR YOUR ATTENTION

Acknowledgements **TÜBİTAK** Project Number: 121M681



9th International Electronic Conference on Sensors and Applications (1–15 November 2022)