

PRODUCTION OF BIOFUELS BY 5-HYDROXYMETHYLFURFURAL ETHERIFICATION USING ION-EXCHANGE RESINS AS SOLID ACID CATALYSTS

<u>Benjamín Torres Olea</u>, Inmaculada Fúñez Nuñez, Cristina García Sancho, Juan Antonio Cecilia, Ramón Moreno Tost, Pedro Jesús Maireles Torres

Departamento de Química Inorgánica, Cristalografía y Mineralogía (Unidad Asociada al ICP-CSIC) Facultad de Ciencias, Universidad de Málaga, Campus de Teatinos, 29071 Málaga, Spain

Fossil fuels are the most important source of fuels, energy and chemicals





Oil refinery in Spain

Corn Field in Liechtenstein. Corn plants are of great importance for the production of biofuels

5-ETHOXYMEHYLFURFURAL (EMF) PRODUCTION FROM HEXOSES



3

OBJECTIVES

Application of different resins in the production of EMF from HMF to identify the most active and selective one OH

 Application of resins to the direct dehydration and etherification of hexoses to EMF



CATALYTIC TESTS AND SAMPLE ANALYSIS



- ^D 5 ml ethanol
- □ 0.05 g catalyst
- ^o 0.1 g HMF / 0.15 g Hexose
- Reactor are degassed with nitrogen before the reaction to avoid secondary unwanted reactions

- Resulting samples were analized through High Pressure Liquid Chromatography (HPLC)
- Products were detected and quantified employing a multiwavelength detector (MD-2015) and a refractive index detector (RI-2031-PLUS)

CATALYSTS CHARACTERIZATION

Catalyst Name	Resin type	Dry ionic exchange capacity (eq·kg ⁻¹)	Mesh size (µm)	BET Surface área (m ² ·g ⁻¹)
Purolite CT275DR	Macroreticular	5,2	425-1200	20-40
Purolite CT269DR	Macroreticular	5,2	425-1200	35-50
Purolite PD206	Gel	4,9	300-1200	-
Amberlyst 15	Macroreticular	>4,7	300-425	53

HMF ETHERIFICATION AT 100°C



HMF conversion under 100°C by using 0.1g HMF and 0.05g of catalyst

Logarithm representation of conversion. Result is akin to a first order reaction.

HMF ETHERIFICATION AT 100°C



HMF ETHERIFICATION VARYING HMF LOADING



Employing different amounts of EMF does not affect conversion rate.

At the same time, different HMF loadings does not seem alter EMF or EMF results notably.



Amberlyst 15 80°C

HMF RESULTS VARYING TEMPERATURE

HEXOSES CONVERSION AT 100°C

Hexose conversion and selectivities towards HMF, EMF and EL after 5 hours of reaction time at 100°C.

Fructose was converted readily to HMF and its derivatives. However, glucose and galactose followed a different reaction path.



CONCLUSIONS

Several resins were assessed in ethanol for the production of EMF from HMF.

- ^D Purolite CT275DR showed the best catalytic results.
- Although HMF loading had no effect in EMF in overall kinetics, temperature plays a major role conversion and selectivity.
- Purolite was able to convert fructose into EMF successfully, however, it was unable to dehydrate aldoses without Lewis acid sites.

THANKS FOR YOUR ATTENTION!

ACKNOWLEDGMENTS







A WAY TO MAKE EUROPE

We thank the financial support provided by the Spanish Ministry of economy and competitiveness (RTI2018-94918-B-C44), FEDER funds for a postdoctoral contract (UMA18-FEDERJA-171), and the University of Malaga.