


Computer vision technique for blind identification of modal frequency of structures from video measurements.

<u>Vishal Allada</u> and <u>T. Jothi Saravanan</u>

School of Infrastructure
Indian Institute of Technology Bhubaneshwar
Odisha, India.









CONTENTS















Objective:

To extract the modal frequencies of the structure from structure's video, by estimating the time history data of the structure, using computer vision techniques like complex steerable pyramids, and separating the modal frequencies using principal component analysis (PCA) and analytical mode decomposition (AMD).





Methododlogy:





Figure 1- Flowchart of proposed method





<u>Validation:</u>

The proposed method is validated on a 10 DOF numerical model








Figure 4 – Principal coordinates of numerical model




Figure 5 – Extracted modes



| Mode | Frequency (Hz) | | Error |
|------|----------------|-----------|-------|
| | Theoretical | Estimated | % |
| 1 | 6.25 | 6.30 | 0.8 |
| 2 | 11.45 | 11.50 | 0.09 |
| 3 | 15.62 | 15.60 | 0.13 |
| 4 | 20.03 | 20.00 | 0.15 |

Table 1 — Results comparison




Results of

Numerical

model

<u>Implementation:</u>









Results of Numerical model




Figure 10 – Modes extracted from video of London
Millennium bridge

| Mode | Frequency (Hz) | | Error |
|------|-------------------------|-----------|-------|
| | From Pavic, A et. Al | Estimated | % |
| - 1 | 0.77 | 0.769 | 0.13 |
| 2 | 1.54 | 1.53 | 0.65 |
| 3 | 2.32 | 2.31 | 0.43 |

Table 2 – Results comparison





Conclusion:

- This study develops a hybrid output-only OMA algorithm that uses PCA and AMD to blindly extract the modal frequencies and modal coordinates from line-of-sight video measurement of the structures
- The 10-DOF dynamic numerical model validation and implementation on London Millennium Bridge resulted in more than 99% accuracy in detecting the modal frequencies.
- Henceforth, the recommended algorithm can be utilized for an effective non-contact OMA using a computer vision monitoring system.



Thank You