



# The 7th International Electronic Conference on Medicinal Chemistry (ECMC 2021)

01-30 NOVEMBER 2021 | ONLINE

## Chitosan-based biocomposites as H<sub>2</sub>S vehicles


Mary Batista<sup>1</sup>, Moisés L. Pinto<sup>2</sup>, Fernando Antunes<sup>2</sup>, João Pires<sup>2\*</sup>, and Silvia Carvalho<sup>1,2\*</sup>

<sup>1</sup> Centro de Química Estrutural, Faculdade de Ciências da Universidade de Lisboa, 1749-016, Lisboa, Portugal;

<sup>2</sup> CERENA, Departamento de Engenharia Química, Instituto Superior Técnico, Universidade de Lisboa, 1049-001, Lisboa, Portugal.

- Corresponding authors: [silvia.carvalho@tecnico.ulisboa.pt](mailto:silvia.carvalho@tecnico.ulisboa.pt) and [jpsilva@fc.ul.pt](mailto:jpsilva@fc.ul.pt)

# Chitosan-based biocomposites as H<sub>2</sub>S vehicles



The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE

# Abstract

Hydrogen sulphide ( $\text{H}_2\text{S}$ ) is commonly known due to its toxicity, and rotten egg smell, yet the detection of endogenously produced  $\text{H}_2\text{S}$  in the brain tissues of mammals in 1989 changed the ways scientists looked at this gas. Currently,  $\text{H}_2\text{S}$  is a gasotransmitter (small gaseous molecules involved in signalling processes) and its exogenous delivery has many potential therapeutic applications (*e.g.*, wound healing, cardiovascular diseases). The therapeutical use of  $\text{H}_2\text{S}$  is challenging, being crucial maintaining its level in the body within the therapeutic window, at the risk of having toxic effects.

In this work, we synthesised chitosan biocomposites using porous materials (type A zeolites and an activated carbon obtained from glycerine) and conducted studies to evaluate the possibility of being used as  $\text{H}_2\text{S}$  vehicles. The biocomposites were characterised and their  $\text{H}_2\text{S}$  adsorption capacity and release profile in aqueous solution at pH 7 were evaluated by volumetric method and Ellman's reagent, respectively. Cytotoxicity assays using HeLa cells for all chitosan biocomposites were performed, as well as for the  $\text{H}_2\text{S}$  loaded material that showed the most promising aqueous solution release results.

**Keywords:** biocomposites; chitosan;  $\text{H}_2\text{S}$  vehicles



The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE


# Introduction



- $H_2S$  is commonly known by its rotten-egg smell and high toxicity;
- However, it is a gasotransmitter and it may have therapeutic applications;
- This application is limited due to delivery problems.



## Porous materials




- Porous materials are solid containing void space;
- Their high surface area led to a high gas payload;
- In recent years, they have been investigated as potential drug vehicles;
- Biocompatibility issues may be overlapped by surface modification with biocompatible polymers.



The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE

## In this work:



The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE

# Results and discussion

## Synthesis




The 7th International Electronic Conference on Medicinal Chemistry


01-30 NOVEMBER 2021 | ONLINE

# Characterisation - FTIR

## Zeolites composites





## Activated carbon materials



The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE

# Characterisation - TG-DSC






Sample	Parent material		Material with Chitosan		Chitosan (%)
	225 °C	525 °C	225 °C	525 °C	
3A	16.5	20.7	16.9	26.1	5.4
4A	17	21.6	17.9	28.4	10.5
5A	17.3	22.7	19.8	28.9	9.1
Gta@600	9.1	53.1	8.3	75.6	23.3







The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE

# Characterisation - XRD and SEM



The presence of chitosan can be observed on the material surface.





The presence of chitosan is not so noticeable in the SEM images as for zeolites biocomposites.



The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE



# Characterisation - N<sub>2</sub> isotherms



	4A	4A@Chi	5A	5A@Chi	Gta@600	Gta@600Chi
$A_{\text{BET}}$ (m <sup>2</sup> /g)	363	48	409	301	466	< 5



# H<sub>2</sub>S Adsorption






	4A	4A@Chi	5A	5A@Chi	Gta@600	Gta@600Chi
H <sub>2</sub> S <sub>max_adsorbed</sub> (mmol <sub>H<sub>2</sub>S</sub> /g <sub>material</sub> )	3.1	0.1	5.2	3.1	2.1	0.5



The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE

# H<sub>2</sub>S release in aqueous solution at pH 7




	3A	3A@Chi	4A	4A@Chi	5A	5A@Chi	Gta@600	Gta@600Chi
H <sub>2</sub> S <sub>released</sub> (mmol <sub>H<sub>2</sub>S</sub> /g <sub>material</sub> )	1.6	0.02	1.35	0.03	1.48	0.98	0.02	0.012
t <sub>max</sub> (min)	17	17	17	17	17	120	17	17



# Cytotoxicity studies


HeLa viability in the presence of unloaded materials (450 µg/mL).

Each bar represents an average (of 3 independent experiments each one with 8 replicates) ± SD.



No toxicity was observed for any of the materials

HeLa viability in the presence of H<sub>2</sub>S loaded material (5A@Chi - 0.5 mg/mL and 2.0 mg/mL). Each bar represents an average (of 3 independent experiments each one with 2 replicates) ± SD.



No toxicity was observed for 5A@Chi H<sub>2</sub>S loaded material



The 7th International Electronic Conference on Medicinal Chemistry

01-30 NOVEMBER 2021 | ONLINE

# Conclusions

---

- The modification of the materials with chitosan was successfully achieved;
- The 5A zeolite showed the higher adsorption capacity for H<sub>2</sub>S;
- The H<sub>2</sub>S release studies in aqueous solutions showed that the composite 5A@Chi had the longest release time (120 min);
- Cytotoxicity studies showed all the materials are no toxic to HeLa cells;
- H<sub>2</sub>S loaded 5A@Chi also showed no cytotoxicity to HeLa cells;
- 5A@Chi are the most promising material for further studies.



**The 7th International Electronic Conference on Medicinal Chemistry**

01-30 NOVEMBER 2021 | ONLINE

# Acknowledgments

This research was financed by Fundação para a Ciência e a Tecnologia (FCT) through projects PTDC/MEDQUI/28721/2017 and developed in the scope of the projects UIDB/00100/2020 (CQE), UIDB/04028/2020 & UIDP/04028/2020 (CERENA), financed by Portuguese funds through the FCT/MEC and when applicable co-financed by FEDER under the PT2020 Partnership Agreement.

Mary Batista acknowledges for FCT-Investigator contract-DL57.



**The 7th International Electronic Conference on Medicinal Chemistry**

01-30 NOVEMBER 2021 | ONLINE