

Mesoporous AuAgCu Alloys with Tuned Defects and Composition for Enhanced Electrochemical Sensing

Author(s)


Hyeongyu Park† (1,2), Aditya Ashok† (3), Mostafa K. Masud (3), Md. Shahriar A. Hossain (3), Yusuf V. Kaneti (3), and Yusuke Yamauchi (3)*

Affiliations

1. Weizmann Institute of Science, Rehovot, Israel 2. Department of Materials Science and Engineering, Seoul National University, Seoul, Republic of Korea 3. Australian Institute for Bioengineering and Nanotechnology (AIBN), The University of Queensland, Brisbane, Australia

INTRODUCTION & AIM

Electrochemical sensors demand electrodes with high surface area and defect control. Mesoporous Au–Ag–Cu alloys on amorphous glass substrates overcome the limits of mono/bimetallic films. The smaller Cu atoms induce compressive strain and uniform defects, yielding optimized $\text{mAu}_{0.6}\text{Ag}_{0.2}\text{Cu}_{0.2}$ films with uniform mesopores, high ECSA, and stable activity. This work demonstrates how composition and strain/defect engineering enable enzyme-free, high-performance sensing.




Soft-templated electrodeposition of mesoporous Au–Ag–Cu

METHOD

1. Soft-templating: PS–PEO micelles
2. Electrodeposition: -0.7 V, 600 s (Au/Ag/Cu salts)
3. Post-treatment: THF rinse
4. Characterization: SEM/TEM/XRD/XPS, CV/DPV/i–t


RESULTS & DISCUSSION




Structural and compositional characterization of mesoporous Au–Ag–Cu: Uniform ~ 22 nm mesopores (SEM/TEM), defects & lattice strain (HRTEM), and homogeneous Au–Ag–Cu distribution (STEM-EDS).

Structure & defects

- Uniform ~ 22 nm pores
- $\sim 5\%$ (200) d-spacing reduction \rightarrow compressive strain
- Twins/dislocations confirmed (FFT/SAED)
- STEM–EDS: homogeneous alloy



(c) Area-normalized DPV response in $[\text{Fe}(\text{CN})_6]^{3-/4-}$
(d) Chronoamperometric glucose sensing.



(a) Ternary compositional map with normalized DPV,
(b) CV stability after 30 cycles in $[\text{Fe}(\text{CN})_6]^{3-/4-}$.

Electrochemistry

- ECSA: 1051 vs Au (844), AuAg (584) $\mu\text{A}\cdot\text{cm}^{-2}$

Glucose sensing

- LOD (intercept-corrected): 40 μM vs Au (104), AuAg (447)
- No amplification, photopatterning, or covalent functionalization

CONCLUSION

- Balanced porosity, strain/defect control, stable activity
- Atomic-level tuning unlocks enzyme-free, sensitive sensing
- Promising for practical biosensing/diagnostics

FUTURE WORK / REFERENCES

- Modified electrode coatings as smart, adaptive, logic-based platforms for reversible protein sensing in post-diagnostic monitoring.

Weizmann Institute of Science
Postdoctoral Research
Associate (non-salaried)



Seoul National University
Visiting Research Fellow

Acknowledgement

This work was conducted at the Australian Institute for Bioengineering and Nanotechnology (AIBN), The University of Queensland (UQ), Australia.
Park et al., ACS Nano, 2025, DOI: 10.1021/acsnano.4c11730
Contact: hyeongyu.park9024@gmail.com

